































| Original | | Rechange | | Original | | Rechange | |
|---|-----------------|---|---------|---|------|---|--------|
|  | Power |  | Power |  | Left |  | Left |
|  | Red/Rec/Instant |  | Red |  | Vol+ |  | Vol + |
|  | Green/<< |  | Green |  | Vol- |  | Vol - |
|  | Yellow/Stop |  | Yellow |  | Mute |  | Mute |
|  | Blue/play |  | Blue |  | P+ |  | Ch + |
|  | White/>>/□ |  | >> |  | P- |  | Ch - |
|  | >◆ |  | D. Menu |  | 1 |  | 1 |
|  | [] |  | Guide |  | 2 |  | 2 |
|  | [o]/Timer |  | Sleep |  | 3 |  | 3 |
|  | [?] |  | Eject |  | 4 |  | 4 |
|  | [◆] |  | Format |  | 5 |  | 5 |
|  | [≡]/Text |  | Text |  | 6 |  | 6 |
|  | Menu |  | Menu |  | 7 |  | 7 |
|  | OK |  | Ok |  | 8 |  | 8 |
|  | Up |  | Up |  | 9 |  | 9 |
|  | Down |  | Down |  | 0 |  | 0 |
|  | Right |  | Right |  | P<P |  | Pre Ch |





| Original | | Recharge | | Original | | Recharge | |
|---|----------------------|---|---------|----------|--|----------|--|
|  | [i+] |  | Info | | | | |
|  | I-II |  | Dual | | | | |
|  | [> <] |  | Subt | | | | |
|  | [1 2] |  | 3D | | | | |
|  | []-> |  | AV | | | | |
|  | Smart |  | Smart | | | | |
|  | [] Smart |  | Media | | | | |
|  | [<>] |  | Back | | | | |
|  | [-o-]/Active Control |  | Options | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |





| Original | | Rechange | | Original | | Rechange | |
|---|-----------------|---|--------|---|------|---|--------|
|  | Power |  | Power |  | Vol- |  | Vol - |
|  | Red/Rec/Instant |  | Red |  | Mute |  | Mute |
|  | Green/Left |  | Green |  | P+ |  | Ch + |
|  | Yellow/Stop |  | Yellow |  | P- |  | Ch - |
|  | Blue/Play |  | Blue |  | 1 |  | 1 |
|  | White/Right |  | >> |  | 2 |  | 2 |
|  | [o]/Timer |  | Sleep |  | 3 |  | 3 |
|  | [?] |  | Eject |  | 4 |  | 4 |
|  | [♦] |  | Format |  | 5 |  | 5 |
|  | [≡]/Text |  | Text |  | 6 |  | 6 |
|  | Menu |  | Menu |  | 7 |  | 7 |
|  | OK |  | Ok |  | 8 |  | 8 |
|  | Up |  | Up |  | 9 |  | 9 |
|  | Down |  | Down |  | 0 |  | 0 |
|  | Right |  | Right |  | P<P |  | Pre Ch |
|  | Left |  | Left |  | [i+] |  | Info |
|  | Vol+ |  | Vol + |  | I-II |  | Dual |













| Original | Rechange | Original | Rechange |
|--|---|----------|----------|
|  [> <] |  Subt | | |
|  [1 2] |  3D | | |
|  []→ |  AV | | |
|  ♪ Smart |  Smart | | |
|  [] Smart |  Media | | |
|  [<>] |  Back | | |
|  [-o-]/Active Control |  Options | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |





| Original | | Rechange | | Original | | Rechange | |
|---|-----------------|---|--------|---|------|---|--------|
|  | Power |  | Power |  | Vol- |  | Vol - |
|  | Red/Rec/Instant |  | Red |  | Mute |  | Mute |
|  | Green/<< |  | Green |  | P+ |  | Ch + |
|  | Yellow/Stop |  | Yellow |  | P- |  | Ch - |
|  | Blue/Play |  | Blue |  | 1 |  | 1 |
|  | White/>>/□ |  | >> |  | 2 |  | 2 |
|  | [o]/Timer |  | Sleep |  | 3 |  | 3 |
|  | [?] |  | Eject |  | 4 |  | 4 |
|  | [♦] |  | Format |  | 5 |  | 5 |
|  | [≡]/Text |  | Text |  | 6 |  | 6 |
|  | Menu |  | Menu |  | 7 |  | 7 |
|  | OK |  | Ok |  | 8 |  | 8 |
|  | Up |  | Up |  | 9 |  | 9 |
|  | Down |  | Down |  | 0 |  | 0 |
|  | Right |  | Right |  | P<P |  | Pre Ch |
|  | Left |  | Left |  | [i+] |  | Info |
|  | Vol+ |  | Vol + |  | I-II |  | Dual |





| Original | Rechange | Original | Rechange |
|----------------------|----------|----------|----------|
| [> <] | Subt | | |
| [1 2] | 3D | | |
| []→ | AV | | |
| ♪ Smart | Smart | | |
| [] Smart | Media | | |
| [<<] | Back | | |
| [-o-]/Active Control | Options | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

