







































































| Original    | Recharge  | Original   | Recharge  |
|-------------|---|------------|---|
| PWR On/Off  |  Power   | OK Enter   |  Ok    |
| Mute        |  Mute  | Menu Right |  Right |
| Epg         |  +  Shift + Guide | Exit       |  Exit  |
| App         |  Media   | Menu Down  |  Down  |
| Opt?        |  Options   | Audio      |  Dual  |
| TV          |  TV/R  | Back       |  Back  |
| Info        |  +  Shift + Info  | Volume+    |  Vol + |
| Subt.List   |  Subt  | CH/Page+   |  Ch +  |
| Sleep Timer |  Sleep   | Volume-    |  Vol - |
| Video       |  D. Menu   | CH/Page-   |  Ch -  |
| Text        |  Text   | 1. ?       |  1    |
| Zoom        |  Eject   | 2abc       |  2   |
| TV/SAT      |  AV  | 3def       |  3   |
| Menu        |  Menu  | 4ghi       |  4   |
| Menu Up     |  Up  | 5jkl       |  5   |
| Display     |  Info  | 6mno       |  6   |
| Menu Left   |  Left  | 7pqrm      |  7   |







































| Original     | Recharge  | Original      | Recharge  |
|--------------|---|---------------|---|
| 8tuv         |  8               | +             |  Shift + Subt    |
| 9wxyz        |  9               | Auth./DISEQC  |  Shift + Smart   |
| Guide Pilote |  GUIDE           | Sys/Serv      |  Shift + Sleep   |
| 0/10         |  0               | Home Cinema   |  Smart           |
| FAV Pref.    |  PRE-CH          | Scan/Setup    |  Shift + Options |
| Red          |  A               | Interat       |  Shift + D. Menu |
| Green        |  B               | Pers.         |  Shift + Eject   |
| Yellow       |  C               | Tune-         |  Shift + Left    |
| Freeze       |  Stop            | East          |  >>I             |
| Blue         |  D               | H/V Play      |  Play            |
| Dev          |  LIST           | LNB F.Forward |  >>             |
| 22Khz        |  3D            | Lang./Rewind  |  <<            |
| West         |  I<<           | Alt/16:9      |  Format        |
| Radio        |  Shift + TV/R  | Aft/Caf       |  Shift + Ok    |
| On/Off       |  Shift + Power | Tune+         |  Shift + Right |
| Dec/Pause    |  Pause         |               |  Shift + Exit  |
|              |  Shift + Mute  | Browse        |  Shift + Back  |



| Original | Recharge                  | Original | Recharge |
|----------|---------------------------|----------|----------|
|          | SHIFT + CH + Shift + Ch + |          |          |
|          | SHIFT + CH - Shift + Ch - |          |          |
| View     | SHIFT + 0 Shift + 0       |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |
|          |                           |          |          |






































| Original    | Recharge  | Original   | Recharge  |
|-------------|---|------------|---|
| PWR On/Off  |  Power   | OK Enter   |  Ok    |
| Mute        |  Mute  | Menu Right |  Right |
| Epg         |  +  Shift + Guide | Exit       |  Exit  |
| Subt.List   |  Subt  | Menu Down  |  Down  |
| Opt?        |  Options   | Back       |  Back  |
| App         |  Media   | Audio      |  Dual  |
| Info        |  +  Shift + Info  | Volume+    |  Vol + |
| Sleep Timer |  Sleep   | CH/Page+   |  Ch +  |
| TV          |  TV/R  | Volume-    |  Vol - |
| Video       |  D. Menu   | CH/Page-   |  Ch -  |
| Text        |  Text   | 1. ?       |  1    |
| Zoom        |  Eject   | 2abc       |  2   |
| TV/SAT      |  AV  | 3def       |  3   |
| Menu        |  Menu  | 4ghi       |  4   |
| Menu Up     |  Up  | 5jkl       |  5   |
| Display     |  Info  | 6mno       |  6   |
| Menu Left   |  Left  | 7pqrm      |  7   |










| Original     | Recharge  | Original     | Recharge  |
|--------------|---|--------------|---|
| 8tuv         |  8   | SAT Sky      |  +  Shift + AV        |
| 9wxyz        |  9   | Navi Mode    |  +  Shift + Menu      |
| Guide Pilote |  Guide   | Browse       |  +  Shift + Media     |
| 0/10         |  0   | Search       |  +  Shift + Up        |
| FAV Pref.    |  Pre Ch  | Auth./DISEQC |  3D  |
| Red          |  Red   | Tune-        |  +  Shift + Left      |
| Green        |  Green   | Tune+        |  +  Shift + Right     |
| Yellow       |  Yellow  | East         |  >>  |
| Blue         |  Blue  | Lang./Rewind |  +  Shift + Exit      |
| On/Off       |  +  Shift + Power     | H/V Play     |  Play   |
| Scan/Setup   |  +  Shift + Options | Store        |  +  Shift + Down  |
| Radio        |  +  Shift + TV/R  | Alt/16:9     |  Format  |
|              |  +  Shift + Mute  | Home Cinema  |  +  Shift + Vol + |
| 22Khz        |  List  |              |  Smart   |
| +            |  +  Shift + Subt  |              |  +  Shift + Vol - |
| Sys/Serv     |  +  Shift + Sleep |              |   |
| Pers.        |  +  Shift + Eject |              |   |







































| Original    | Recharge   | Original  | Recharge  |
|-------------|--|-----------|---|
| PWR On/Off  |  Power  | Exit      |  Exit  |
| Mute        |  Mute   | Menu Down |  Down  |
| Opt?        |  Options  | Back      |  Back  |
| Info        |  +  Shift + Info | Volume+   |  Vol + |
| Subt.List   |  Subt   | CH/Page+  |  Ch +  |
| Sleep Timer |  Sleep  | Audio     |  Dual  |
| TV          |  TV/R   | Volume-   |  Vol - |
| Video       |  D. Menu  | CH/Page-  |  Ch -  |
| Text        |  Text   | 1. ?      |  1     |
| Zoom        |  Eject  | 2abc      |  2     |
| TV/SAT      |  AV  | 3def      |  3    |
| Menu        |  Menu   | 4ghi      |  4   |
| Menu Up     |  Up   | 5jkl      |  5   |
| Display     |  Info   | 6mno      |  6   |
| Menu Left   |  Left   | 7pqrm     |  7   |
| OK Enter    |  Ok   | 8tuv      |  8   |
| Menu Right  |  Right  | 9wxyz     |  9   |



| Original      | Recharge   | Original | Recharge |
|---------------|--|----------|----------|
| Guide Pilote  |  Guide    |          |          |
| 0/10          |  0        |          |          |
| FAV Pref.     |  Pre Ch   |          |          |
| Red           |  Red      |          |          |
| Green         |  Green    |          |          |
| Dec/Pause     |  Pause    |          |          |
| Lang./Rewind  |  <<       |          |          |
| Freeze        |  Stop     |          |          |
| LNB F.Forward |  >>       |          |          |
| H/V Play      |  Play     |          |          |
| East          |  >>      |          |          |
| Yellow        |  Yellow |          |          |
| Blue          |  Blue   |          |          |
|               |  |          |          |
|               |  |          |          |
|               |  |          |          |
|               |  |          |          |



| Original    | Recharge  | Original   | Recharge  |
|-------------|---|------------|---|
| PWR On/Off  |  Power   | OK Enter   |  Ok    |
| Mute        |  Mute  | Menu Right |  Right |
| Epg         |  +  Shift + Guide | Exit       |  Exit  |
| Subt.List   |  Subt  | Menu Down  |  Down  |
| Opt?        |  Options   | Back       |  Back  |
| App         |  Media   | Audio      |  Dual  |
| Info        |  +  Shift + Info  | Volume+    |  Vol + |
| Sleep Timer |  Sleep   | CH/Page+   |  Ch +  |
| TV          |  TV/R  | Volume-    |  Vol - |
| Video       |  D. Menu   | CH/Page-   |  Ch -  |
| Text        |  Text   | 1. ?       |  1    |
| Zoom        |  Eject   | 2abc       |  2   |
| TV/SAT      |  AV  | 3def       |  3   |
| Menu        |  Menu  | 4ghi       |  4   |
| Menu Up     |  Up  | 5jkl       |  5   |
| Display     |  Info  | 6mno       |  6   |
| Menu Left   |  Left  | 7pqrm      |  7   |





| Original     | Recharge  | Original    | Recharge   |
|--------------|---|-------------|--|
| 8tuv         |  8   | 22Khz       |  List   |
| 9wxyz        |  9   | Radio       |  +  Shift + TV/R     |
| Guide Pilote |  Guide   | Navi Mode   |  +  Shift + Menu     |
| 0/10         |  0   | Search      |  +  Shift + Up       |
| FAV Pref.    |  Pre Ch  | Tune-       |  +  Shift + Left     |
| Red          |  Red   | Tune+       |  +  Shift + Right    |
| Green        |  Green   | Store       |  +  Shift + Exit     |
| Yellow       |  Yellow  |             |  +  Shift + Down     |
| Blue         |  Blue  |             |  +  Shift + Vol +    |
| On/Off       |  +  Shift + Power       |             |  +  Shift + Ch +     |
| Scan/Setup   |  +  Shift + Options   |             |  +  Shift + Vol -  |
|              |  +  Shift + Mute    | Home Cinema |  Smart  |
| Dec/Pause    |  Pause   |             |  +  Shift + Ch - |
| +            |  +  Shift + Subt    | De-emph     |  +  Shift + 1    |
| Sys/Serv     |  +  Shift + Sleep   | Swap        |  +  Shift + 2    |
| Interat      |  +  Shift + D. Menu | P.lock      |  +  Shift + 3    |
| SAT Sky      |  +  Shift + AV      | Wn          |  +  Shift + 4    |



| Original     | Recharge  | Original | Recharge |
|--------------|---|----------|----------|
| 50j17        |  +  Shift + 5 |          |          |
| Auth./DISEQC |  3D 3D   |          |          |
| Help         |  +  Shift + 6 |          |          |
| Copy/Delete  |  +  Shift + 7 |          |          |
| Erase        |  +  Shift + 8 |          |          |
| View         |  +  Shift + 0 |          |          |
| Alt/16:9     |  Format  |          |          |
|              |   |          |          |
|              |   |          |          |
|              |   |          |          |
|              |   |          |          |
|              |   |          |          |
|              |   |          |          |
|              |   |          |          |
|              |   |          |          |
|              |   |          |          |
|              |   |          |          |
|              |   |          |          |
|              |   |          |          |

