






















































	Original	Rechange	Original	Rechange
POWER	 Power	 Power	 Stop	 Stop
P/N	 P/N	 Pre Ch	 Pause	 Pause
VGA	 VGA	 Format	 Photo	 Red
SETUP	 Setup	 Options	 Music	 Green
AUDIO	 Audio	 Dual	 Video	 Yellow
R/L	 R/L	 Guide	 File	 Blue
SLIDE	 Slide	 Back	 Up	 Up
A-B	 A-B	 TV/R	 Down	 Down
TOP	 Top	 Media	 Right	 Right
SUBTI	 Subti	 Subt	 Left	 Left
VOL+	 Vol+	 Vol +	 Enter	 Ok
VOL-	 Vol-	 Vol -	 Menu	 Menu
MUTE	 Mute	 Mute	 Func.	 Smart
<<<	 <<<	 <<<	 Repeat	 Text
>>>	 >>>	 >>>	 Slow	 AV
I<<<	 I<<<	 I<<<	 Delay	 Info
>>I	 >>I	 >>I	 Trans	 List



