









































Original	Recharge
 Power	 Power
 Mute	 Mute
 Pause	 Pause
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Back
 Scan	 Smart
 Menu	 Menu
 MP	 Media

Original	Recharge
 Info	 Info
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Page+	 Ch +
 Page-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 FAV	 Pre Ch
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 SAT	 Options





Original		Recharge		Original		Recharge	
	Audio		Dual				
	Tv/Radio		TV/R				

