







































































| Original | Rechange |
|---|--|
|  Power |  Power |
|  Mute |  Mute |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  DTV/ATV |  Info |
|  Recall |  Pre Ch |
|  P.Mode |  Shift + Format |
|  S.Mode |  Shift + Dual |
|  Sleep |  Sleep |

| Original | Rechange |
|--|---|
|  Menu |  Menu |
|  Source |  AV |
|  Enter |  Ok |
|  Up |  Up |
|  Down |  Down |
|  Left |  Left |
|  Right |  Right |
|  Exit |  Exit |
|  Display |  Shift + Info |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  CH+ |  Ch + |
|  CH- |  Ch - |
|  MTS |  Shift + Sleep |
|  Rec List |  D. Menu |
|  FAV/List |  Dual |
|  Rec |  Rec |



**Original****Rechange**

| | | | |
|---|--------------------------|--|--------------------|
|  | Freeze |  | Options |
|  | <</Guide |  | << |
|  | >>/Aspect |  | >> |
|  | I<</Cancel |  +  | Shift + Subt |
|  | >>I/Sub.Pg |  | Back |
|  | Stop/Index |  | Stop |
|  | Play/Pause/Time Shift |  | Play |
|  | Tv/Radio |  | TV/R |
|  | Subtitle |  | Subt |
|  | Reveal |  +  | Shift + Options |
|  | Size |  | Format |
|  | Hold |  | Eject |
|  | Text |  | Text |
|  | Red |  | Red |
|  | Green |  | Green |
|  | Yellow |  | Yellow |
|  | Cyan |  | Blue |

Original**Rechange**

| | | | |
|--|--|--|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

