







































































Original		Rechange		Original		Rechange	
	Power		Power		Vol+		Vol +
	Mute		Mute		Vol-		Vol -
	DVB/Analogue		Smart		PR/Page+		Ch +
	AV		AV		PR/Page-		Ch -
	Sleep		Sleep		Up/[≡▲]		Up
	1		1		Down/[≡▼]		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK/Select		Ok
	5		5		Guide		Guide
	6		6		Subtitle		Subt
	7		7		Language		Dual
	8		8		Favourite		Pre Ch
	9		9		Prev PR		Back
	0		0		Menu		Menu
	S.Effect		Media		Aspect		3D
	▼/O/I/I/I	 	Shift + Dual		Normal		Options





Original		Rechange		Original		Rechange	
	[i]/Recall		Info				
	Cancel/Exit		Exit				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	[≡]/Text		Text				
	[≡?]/Reveal		TV/R				
	[≡x]/T.Cancel		Eject				
	[≡♦]/Size		Format				
	[≡o]/Subcode		D. Menu				
	[≡+]/Hold		Shift + TV/R				
	[≡i]/Index		List				
	Game		Shift + Smart				

