



| Original | Recharge |
|------------|-----------------------------|
| Power | Power |
| Tv/Rad | TV/Radio / |
| Tv/SAT | Smart / List |
| Red/Opt | Red / Netflix / Search |
| Red/Opt | Setup / OPT / |
| Green/A/V+ | Green / APP / Repeat |
| Yellow/FAV | Yellow / YouTube / Repeat |
| Yellow/FAV | Fav / Marker / PC |
| Blue/A-Z | Blue / Prime Video / Random |
| Menu | Menu / Home |
| EPG | Guide / EPG / -/-- |
| Info | Info / Angle |
| Up | Up |
| Left | Left |
| OK | OK |
| Right | Right |
| Down | Down |

| Original | Recharge |
|----------|-----------------------|
| V+ | Vol+ |
| Recall | Back / Return |
| P+ | CH+ / Page+ |
| V- | Vol- |
| P- | CH- / Page- |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| Pause | Pause / Step / Freeze |
| 0 | 0 |
| Mute | Mute / Dimmer |

