



| Original | | Rechange | | Original | | Rechange | |
|----------|--------|----------|---------|----------|----------|----------|--------|
| | Power | | Power | | 0 | | 0 |
| | Tv/SAT | | Smart | | P+ | | Ch + |
| | Mute | | Mute | | P- | | Ch - |
| | TV/R | | TV/R | | Recall | | Back |
| | Goto | | Options | | DEV | | Media |
| | Audio | | Dual | | Up/CH+ | | Up |
| | Aspect | | 3D | | Down/CH- | | Down |
| | Info | | Info | | Right | | Right |
| | 1 | | 1 | | Left | | Left |
| | 2 | | 2 | | OK | | Ok |
| | 3 | | 3 | | Vol+ | | Vol + |
| | 4 | | 4 | | Vol- | | Vol - |
| | 5 | | 5 | | Menu | | Menu |
| | 6 | | 6 | | EPG | | Guide |
| | 7 | | 7 | | FAV | | Pre Ch |
| | 8 | | 8 | | Exit | | Exit |
| | 9 | | 9 | | TTX | | Text |





| Original | | Rechange | | Original | | Rechange | |
|---|-------------|---|--------|----------|--|----------|--|
|  | Red |  | Red | | | | |
|  | Green |  | Green | | | | |
|  | Yellow |  | Yellow | | | | |
|  | Blue/Option |  | Blue | | | | |
|  | Subt. |  | Subt | | | | |
|  | Zoom |  | Eject | | | | |
|  | << |  | << | | | | |
|  | >> |  | >> | | | | |
|  | Play |  | Play | | | | |
|  | Pause |  | Pause | | | | |
|  | Stop |  | Stop | | | | |
|  | Rec |  | Rec | | | | |
|  | MP |  | AV | | | | |
|  | V-Format |  | Format | | | | |
|  | A1 |  | List | | | | |
|  | B2 |  | Sleep | | | | |

