







































































Original		Rechange		Original		Rechange	
	Power		Power		Vol+		Vol+
	e/Energy/Savin		Sleep / Timer		FAV/Mark		Fav / Marker / PC
	AV Mode		Eject / Surround		P+		CH+ / Page+
	Input		AV / Input / RDS		Vol-		Vol-
	TV/RAD		TV/Radio /		Ratio		Picture / Format
	1		1		P-		CH- / Page-
	2		2		Mute		Mute / Dimmer
	3		3		Menu		Menu / Home
	4		4		Guide		Guide / EPG / -/-
	5		5		Q.Menu		D.Menu / Top
	6		6		Up		Up
	7		7		Left		Left
	8		8		OK		OK
	9		9		Right		Right
	List		Smart / List		Down		Down
	0		0		Back		Back / Return
	Q.View		Display / Media		Info		Info / Angle





Original		Recharge		Original	Recharge
	Exit		Exit / Cancel / Clear		
	Red		Red / Netflix / Search		
	Green		Green / APP / Repeat		
	Yellow		Yellow / YouTube / Repeat		
	Blue		Blue / Prime Video / Random		
	Text		Text / Goto		
	T.Opt		Setup / OPT /		
	Subtitle		Subtitle / EQ		
	Stop		Stop / Hold		
	Play		Play / Slow		
	Pause		Pause / Step / Freeze		
	<<		<< / Tune-		
	>>		>> / Tune+		
	Simplink		Zoom / Size		
	AD		Audio / Lang I/II		

