
























	Original	Recharge	Original	Recharge
	OK	Ok		
	Power	Power		
	Back	Back		
	Home/Smart	Media		
	Up	Up		
	Down	Down		
	Left	Left		
	Right	Right		
	3D	3D		
	Mute	Mute		
	Ch+	Ch +		
	Ch-	Ch -		
	Vol+	Vol +		
	Vol-	Vol -		
	Wheel Up	2		
	Wheel Down	8		







































Original	Recharge
Power	 Power
Wheel Down	 +  Shift + Down
OK	 Ok
Up	 Up
Down	 Down
Wheel Up	 +  Shift + Up
Right	 Right
Left	 Left
Back	 Back
Home / Smart	 Smart
3D	 3D
123 / Q.Menu	 +  Shift + Ok
Vol +	 Vol +
Vol -	 Vol -
Mute	 Mute
P +	 Ch +
P -	 Ch -

Original	Recharge
Ratio	 Format
List	 List
Q.Menu	 +  Shift + Menu
Subtitle	 Subt
Settings	 +  Shift + Options
AD / PIP	 Dual
>>	 >>
>>>	 >>I
Play	 Play
<<<	 <<<
<<	 I<<<
Rec	 Rec
Pause	 Pause
Stop / Live TV	 Stop
AV Mode	 +  Shift + AV
Text	 Text
FAV	 +  Shift + Pre Ch





Original	Rechange	Original	Rechange
Exit	 Exit		Exit
TV / PC	 +  Shift + Smart		Shift + Smart
Input	 AV		AV
TV / Radio	 TV/R		TV/R
Blue	 D		Blue
Yellow	 C		Yellow
Green	 B		Green
Red	 A		Red
0	 0		0
AD	 +  Shift + Subt		Shift + Subt
Search	 +  Shift + TV/R		Shift + TV/R
Live Menu	 MENU		Menu
Recent	 PRE-CH		Pre Ch
Live Zoom	 		Eject
App	 +  Shift + Media		Shift + Media
Guide	 GUIDE		Guide
Info	 INFO		Info

Original	Rechange	Original	Rechange
T.Opt	 OPT		Options
Q.View	 D. MENU		D. Menu
Energy Saving	 +  Shift + 3D		Shift + 3D
9	 9		9
8	 8		8
7	 7		7
6	 6		6
5	 5		5
4	 4		4
3	 3		3
2	 2		2
1	 1		1
My APPS	 MEDIA		Media

