





| Original | | Rechange | | Original | | Rechange | |
|---|-----------------|---|---------|---|----------|---|---------------|
|  | Power |  | Power |  | 5 |  | 5 |
|  | Red/Sound ↑ |  | Red |  | 6 |  | 6 |
|  | Green/Picture/↓ |  | Green |  | 7 |  | 7 |
|  | Yellow/Feature |  | Yellow |  | 8 |  | 8 |
|  | Blue/Install |  | Blue |  | 9 |  | 9 |
|  | [≡] |  | Text |  | 0 |  | 0 |
|  | [≡0] |  | Options |  | P<P |  | Pre Ch |
|  | [≡+] |  | Subt |  | -/-- |  | Shift + Guide |
|  | [≡x]/[· ·] |  | Format |  | Vol+ |  | Vol + |
|  | [/≡]/[*] |  | Back |  | Vol- |  | Vol - |
|  | [+](≡♦)/Wide |  | 3D |  | Mute |  | Mute |
|  | [≡?]/PC |  | Smart |  | P+ |  | Ch + |
|  | [≡i]/Guide |  | Guide |  | P- |  | Ch - |
|  | 1 |  | 1 |  | I-II |  | Dual |
|  | 2 |  | 2 |  | [i]/Info |  | Info |
|  | 3 |  | 3 |  | TV/DTV |  | TV/R |
|  | 4 |  | 4 |  | AV |  | AV |



