



































































	Original	Rechange	Original	Rechange
	Power			Subpage
	Mute			Pre-CH
	Display			PC
	CH+			Tv/Video
	CH-			Sleep
	Vol+			Sound
	Vol-			Up
	1			Down
	2			Right
	3			Left
	4			Menu
	5			Mix
	6			Teletext
	7			Text Size
	8			Red
	9			Green
	0			Yellow
				Media
				Pre Ch
				Smart
				TV/R
				Sleep
				Dual
				Up
				Down
				Right
				Left
				Menu
				AV
				Text
				Format
				Red
				Green
				Yellow



