


























































Original		Rechange		Original		Rechange	
	Power		Power		P/Pg-		Ch -
	Mute		Mute		Menu		Menu
	Tv/Rad		TV/R		Exit		Exit
	Camera		3D		Vol+		Vol +
	1		1		Vol-		Vol -
	2		2		Up		Up
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Right		Right
	6		6		Down		Down
	7		7		V		AV
	8		8		i		Info
	9		9		Messages		Shift + 1
	0		0		Music		Shift + 2
	EPG		Guide		Movie		Shift + 3
	RCL		Smart		FAV		Pre Ch
	P/Pg+		Ch +		Red		Red






















































Original		Recharge		Original		Recharge	
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Rec		Rec				
	<<		<<				
	Play		Play				
	>>		>>				
	Recall		Back				
	>		Options				
	Stop		Stop				
	Pause		Pause				
	[]]		Format				
	[...]		Subt				
	[≡]		Text				
	Sound		Dual				
































































Original		Rechange		Original		Rechange	
	Power		Power		P/Pg+		Ch +
	Mute		Mute		P/Pg-		Ch -
	1		1		OK		Ok
	2		2		Up		Up
	3		3		Down		Down
	4		4		Right		Right
	5		5		Left		Left
	6		6		Red		Red
	7		7		Green		Green
	8		8		Yellow		Yellow
	9		9		Blue		Blue
	0		0		Rec		Rec
	EPG		Guide		[...]		Subt
	RCL		Smart		[≡]		Text
	Menu		Menu				
	Vol+		Vol +				
	Vol-		Vol -				





Original		Rechange		Original		Rechange	
	Power		Power		P/Pg-		Ch -
	Mute		Mute		Menu		Menu
	Tv/Rad		TV/R		Exit		Exit
	Camera		3D		Vol+		Vol +
	1		1		Vol-		Vol -
	2		2		Up		Up
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Right		Right
	6		6		Down		Down
	7		7		V		AV
	8		8		i		Info
	9		9		Messages		Shift + 1
	0		0		Music		Shift + 2
	EPG		Guide		Movie		Shift + 3
	RCL		Smart		FAV		Pre Ch
	P/Pg+		Ch +		Red		Red





Original		Rechange		Original		Rechange	
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Rec		Rec				
	<<		<<				
	Play		Play				
	>>		>>				
	Recall		Back				
	>		Options				
	Stop		Stop				
	Pause		Pause				
	[]]		Format				
	[...]		Subt				
	[≡]		Text				
	Sound		Dual				

