



Original	Rechange	Original	Rechange
Power	Power	9	9
TV	Smart / List	Sol-	<< / Tune-
Text	Text / Goto	Sol+	>> / Tune+
Source 2	Shift + AV / Input / RDS	=>	Shift + CH- /
Source 1	AV / Input / RDS	0	0
1	1	- / - / =>	Shift + CH+ /
2	2	- / - / =>	Guide / EPG / - / -
3	3	Fa-	Left
Contrast-	I<< / Preset-	Fa+	Right
Contrast+	>>I / Preset+	Vol-	Vol-
4	4	Vol+	Vol+
5	5	><-	CH- / Page-
6	6	><+	CH+ / Page+
Brightness-	Down	OO	Sound / Title
Brightness+	Up	I-II	Audio / Lang I/II
7	7	[]	Zoom / Size
8	8	Mute	Mute / Dimmer



