







































































Original	Rechange	Original	Rechange
 Power	 Power	 PR-	 Ch -
 Source	 AV	 Mute	 Mute
 1	 1	 Ch.List	 List
 2	 2	 Media.P	 Media
 3	 3	 Menu	 Menu
 4	 4	 Guide	 Guide
 5	 5	 Tools	 Options
 6	 6	 Info	 Info
 7	 7	 Return	 Back
 8	 8	 Exit	 Exit
 9	 9	 Enter	 Ok
 0	 0	 Up	 Up
 TTX/MIX	 Text	 Down	 Down
 PRE-CH	 Pre Ch	 Right	 Right
 Vol+	 Vol +	 Left	 Left
 Vol-	 Vol -	 Red	 Red
 PR+	 Ch +	 Green	 Green





Original		Rechange		Original		Rechange	
	Yellow		Yellow				
	Blue		Blue				
	P.Mode	 + 	Shift + Format				
	S.Mode	 + 	Shift + Dual				
	Dual I/II		Dual				
	AD	 + 	Shift + Subt				
	P.Size		Format				
	Subt.		Subt				
	<<		<<				
	Pause		Pause				
	>>		>>				
	Rec		Rec				
	Play		Play				
	Stop		Stop				

