

















































	Original	Recharge	Original	Recharge
	Power			Text
	Goto			Dual
	Mute			Media
	Source			3D
	1			Stop
	2			Play
	3			Pause
	4			Format
	5			Options
	6			Up
	7			Down
	8			Right
	9			Left
	0			Ok
	10+			Yellow
	Step			Red
	Subtitle			Green



