







































































Original	Recharge	Original	Recharge
 Power	 Power	 Return	 Shift + Back
 1	 1	 Tools	 Options
 2	 2	 Source	 AV
 3	 3	 [i+]	 Info
 4	 4	 [I]	 Guide
 5	 5	 Red	 Red
 6	 6	 Green	 Green
 7	 7	 Yellow	 Yellow
 8	 8	 Blue	 Blue
 9	 9	 [+]	 3D
 0	 0	 [> <]	 Format
 Text	 Text	 A/B	 TV/R
 Back	 Back	 Up	 Up
 Menu	 Menu	 Down	 Down
 Digital	 Smart	 Right	 Right
 Analog	 Media	 Left	 Left
 Theatre	 Pre Ch	 OK	 Ok



