























































	Original	Recharge		Original	Recharge
	Continue	 Options		Repeat	 Text
	Shuffle	 TV/R		Fader	 Mute
	Program	 Sleep		Play	 Play
	1	 1		Pause	 Pause
	2	 2		Stop	 Stop
	3	 3		I<< AMS	 I<<
	4	 4		AMS >>I	 >>I
	5	 5		<<	 <<
	6	 6		>>	 >>
	7	 7			
	8	 8			
	9	 9			
	10	 0			
	>10	 Guide			
	Clear	 Exit			
	Time	 AV			
	Check	 Media			

