






























































































Original		Rechange		Original		Rechange	
	Power		Power		C		Pre Ch
	Mute		Mute		[*]		TV/R
	[]		Smart		[↔*]		Subt
	[≡]		Text		[↑*]		List
	Input		AV		[↑]		Options
	Output		Media		Red		Red
	1		1		Green		Green
	2		2		Yellow		Yellow
	3		3		Blue		Blue
	4		4		[≡+]		3D
	5		5		[+]		Info
	6		6		SAT		Back
	7		7		Prog+		Ch +
	8		8		Prog-		Ch -
	9		9		Vol+		Vol +
	0		0		Vol-		Vol -
	-/--		Guide		Picture		Format





Original	Recharge	Original	Recharge
	 Dual		
	 Left		
	 Up		
	 Down		
	 Menu		
	 Ok		
	 Shift + Power		
	 >>		
	 Play		
	 <<		
	 Stop		
	 Pause		
	 Shift + Ch +		
	 Shift + Ch -		



