



	Original	Rechange	Original	Rechange
	Power			Exit
	Mute			Up
	1			Down
	2			Right
	3			Left
	4			Ok
	5			Vol +
	6			Vol -
	7			Shift + Dual
	8			Options
	9			Ch +
	0			Ch -
	Audio			Sleep
	Recall			3D
	Tv-Menu			Shift + Media
	Source			TV/R
	CH.List			Text





Original	Recharge
 EPG	 Guide
 FAV	 Pre Ch
 Info	 Info
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Reveal	 Eject
 Hold	 D. Menu
 List	 Smart
 Index	 Shift + Info
 Subpage	 Shift + Subt
 Size	 Format
 MIX	 Media
 Subtitle	 Subt
 <<	 <<
 >>	 >>

Original	Recharge
 I<<	 I<<
 >>I	 >>I
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 Rec/Rep	 Rec

