







































































Original	Recharge	Original	Recharge
 Power	 Power	 Mute	 Mute
 TRK+	 Shift + Right	 PR+	 Ch +
 TRK-	 Shift + Left	 PR-	 Ch -
 Red/Pref.	 Red	 1	 1
 Green/Showvie	 Green	 2	 2
 Yellow/Info	 Yellow	 3	 3
 Blue/Tv Time	 Blue	 4	 4
 Violet/Text	 Text	 5	 5
 Exit	 Exit	 6	 6
 Menu	 Menu	 7	 7
 Up/VPS	 Up	 8	 8
 Down/Goto	 Down	 9	 9
 Right/>>>I	 Right	 0/--	 0
 Left/I<<	 Left	 AV	 AV
 OK	 Ok	 >>	 >>
 Vol+	 Vol +	 000	 Media
 Vol-	 Vol -	 <<	 <<



