





























































Original		Recharge		Original		Recharge	
	Power		Power		PR-		CH- / Page-
	Green/Timer/List		Green / APP / Repeat		1		1
	Yellow/Info		Yellow / YouTube / Repeat		2		2
	Blue/[^]		Blue / Prime Video / Random		3		3
	Red/[o]		Red / Netflix / Search		4		4
	Up		Up		5		5
	Violet/Text		Text / Goto		6		6
	Left		Left		7		7
	OK		OK		8		8
	Right		Right		9		9
	Exit		Exit / Cancel / Clear		AV		AV / Input / RDS
	Menu		Menu / Home		0/--		0
	Vol+		Vol+				
	Down		Down				
	PR+		CH+ / Page+				
	Mute		Mute / Dimmer				
	Vol-		Vol-				

