



Original	Rechange
Standby	Power
Mute	Mute
AV	AV
Tv/Rad	TV/R
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Menu	Menu
TXT	Text
Back	Back

Original	Rechange
Exit	Exit
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Vol+	Vol +
Vol-	Vol -
Audio	Dual
Info	Info
Sub	Subt
List	List
CH+	Ch +





	Original	Rechange	Original	Rechange
	CH-	 Ch -		
	APP	 Media		
	EPG	 Guide		
	I<<	 I<<		
	<<	 <<		
	>>	 >>		
	>>I	 >>I		
	Rec	 Rec		
	Play	 Play		
	Pause	 Pause		
	Stop	 Stop		
	File	 Smart		

