Mandis shop

APPLE APPLE TV

Original		Replacement	
	Up		Up
	Left		Left
	OK	OK	OK
	Right		Right
	Down		Down
MENU	Menu	HOME MENU	Menu / Home
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze

Original	Replacement

https://mandisremotes.com/en/APPLE/1063935-79779-replacement-remote-control-for-APPLE-Apple-Tv.html