Mandis shop

APPLE APPLE TV

Original	Replacement	Original	Replacement
Up	Up		
Left	Left		
OK	OK		
Right	Right		
Down	Down		
Menu	Menu / Home		
Play	Play / Slow		
Pause	Pause / Step / Freeze		

https://mandisremotes.com/en/APPLE/1063935-79779-replacement-remote-control-for-APPLE-Apple-Tv.html