Original	Replacement	Original	Replacement
Power	Power	P+	Ch +
1	1	P-	Ch -
2	2	Guide	Guide
3	3	Home	Smart
4	4	i	Info
5	5	Back	Back
6	6	Exit	Exit
7	7	Up	Up
8	8	Down	Down
9	9	Right	Right
0	0	Left	Left
Lang	Dual	OK	Ok
TXT	Text	Netflix	Media
Vol +	Vol +	YouTube	Shift + Media
Vol -	Vol -	☼1	Format
Mute	Mute	☼2	3D
Source	AV	Red	Red

Mandis shop

RC43135

Original		Replacement		Original	Replacement
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	<<		<<		
	Pause		Pause		
	>>		>>		
	Rec		Rec		
	Play		Play		
	Stop		Stop		