Mandis shop

TP114

Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Tv/Radio	SEARCH TV/R	TV/R
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Replacement	
OK LIST	OK/List	OK	Ok
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
GUIDE	Guide	-/-- GUIDE	Guide
	Recall	RETURN BACK	Back
FAV	Green/FAV	B	Green
	Red/Audio/Subtitl	A	Red
UHF	Yellow/UHF	C	Yellow
i	Blue/i	D	Blue

https://mandisremotes.com/en/Topfield/1061981-66153-replacement-remote-control-for-Topfield-TP114.html