Mandis shop

Samsung AH81-11699A

Original		Replacement	
	Power		Power
SURROUND	Surround	AD SUBT	Subt
STANDARD	Standard	SOUND DUAL	Dual
BASS	Bass Up	CH +	Ch +
BASS	Bass Down	CH −	Ch -
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
	Mute	MUTE	Mute
D.IN	D. In	D	Blue
AUX	AUX	A	Red
USB RANDOM	USB Random	B	Green
PAIR	Bluetooth Pair	APP MEDIA	Media
	Bluetooth	HOME SMART	Smart
USB	USB ↔	C	Yellow
	>>I		>>I
	I <<		I <<
	Play	PLAY MODE	Play

Original		Replacement	
	Pause		Pause

https://mandis.tv/samsung/10218-336-replacement-remote-control-for-samsung-ah81-11699a.htm