Original	Replacement	Original	Replacement
System Power	Power	Play/Pause	Pause
Title/Characte	List	Play/Pause MD	Ok
Time	AV	Play/Pause CD	Play
Random/RDS	Subt	Vol +	Vol +
Edit	Options	Vol -	Vol -
<< Tuning	<<	Disc Skip	TV/R
>> Tuning Up	>>	Call/Panel	Back
Enter Memory	Dual	Display	Info
Sleep	Sleep	1	1
Repeat/PTY	Text	2	2
Tuner	Smart	3	3
Tone/SDB	Format	4	4
Function	Menu	5	5
>>I/+/Preset	>>I	6	6
I<</-/Preset	I<<	7	7
Prog/Direct/Grou CT	Media	8	8
Stop/Band	Stop	9	9

Original		Replacement	
10	10	0	0
+10	+10	GUIDE	Gui de
CLEAR	Cl ear	CLEAR EXIT	Exi t
◄	Tape <	◄	Lef t
►	Tape >	►	Ri ght

Original	Replacement