Mandis shop

CABASSE

Original		Replacement		Original	Replacement
	Power		Power		
	Mute	DIMMER MUTE	Mute / Dimmer		
	[)(]	SURROUND	Eject / Surround		
HDMI IN	HDMI In	HDMI - SAT 0	0		
	+	+ VOL	Vol+		
	[+]	FORMAT PICTURE	Picture / Format		
TV ARC	Tv ARC	TV 1	1		
	-	VOL −	Vol-		
	Sleep	TIMER SLEEP	Sleep / Timer		
S/PDIF	S/PDIF	OPT-TOOLS SETUP	Setup / OPT /		
BASS	Bass	LANG I/II AUDIO	Audio / Lang I/II		
	♫	TITLE SOUND	Sound / Title		
	Bluetooth	BLUETOOTH 9	9		
	Receptor	USB 8	8		
STD	STD	EQ SUBTITLE	Subtitle / EQ		

https://mandisremotes.com/en/ORANGE/1066294-94130-replacement-remote-control-for-ORANGE-CABASSE.html