| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Up | Up |
| Source | AV / Input / RDS | Down | Down |
| 1 | 1 | Left | Left |
| 2 | 2 | Right | Right |
| 3 | 3 | OK | OK |
| 4 | 4 | Back | Back / Return |
| 5 | 5 | Home | Shift + Menu / |
| 6 | 6 | Exit | Exit / Cancel / Clear |
| 7 | 7 | Vol + | Vol + |
| 8 | 8 | Vol - | Vol - |
| 9 | 9 | CH+ | CH+ / Page+ |
| 0 | 0 | CH- | CH- / Page- |
| Mute | Mute / Dimmer | Netflix | Shift + Red / Netflix / |
| Guide | Guide / EPG / -/-- | prime video | Shift + Blue / Prime |
| Menu | Menu / Home | YouTube | Shift + Yellow / YouTube / |
| Smart Colors | Smart / List | FPlay | Shift + Green / APP / |
| Info | Info / Angle | Audio | Audio / Lang I/II |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| SUB | Sub | EQ SUBTITLE | Subtitle / EQ | | |
| TEXT | Text | GOTO TEXT | Text / Goto | | |
| TV | TV | PROGRAM TV/RADIO | TV/Radio / | | |
| ⏯ | Play | SLOW ▶ | Play / Slow | | |
| ⏯ | Pause | STEP-FREEZE ⏸ | Pause / Step / Freeze | | |
| ◀◀ | << | TUNE- ◀◀ | << / Tune- | | |
| ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ | | |
| ■ | Stop | HOLD ■ | Stop / Hold | | |
| | Red | NETFLIX SEARCH | Red / Netflix / Search | | |
| | Green | APP REPEAT | Green / APP / Repeat | | |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random | | |