Mandis shop

RC-100

Original	Replacement	Original	Replacement
Play	Play / Slow		
Rec Mute	Mute / Dimmer		
<< Rew /	<< / Tune-		
>> F.Fwd / Cue	>> / Tune+		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		

https://mandisremotes.com/en/Aiwa/1067224-95160-replacement-remote-control-for-Aiwa-RC-100.html