Mandis shop

LG AKB73616006

Original	Replacement
Start	Power
Home	Menu / Home
Mode	Setup / OPT /
Turbo	Smart / List
Up	Up
Left	Left
Stop/OK	OK
Stop/OK	Stop / Hold
Right	Right
Down	Down
Repeat	Green / APP / Repeat
My Space	Display / Media
Nothing 1	1
Mute	Mute / Dimmer
Nothing 2	2
Diagnosis	D.Menu / Top

Original	Replacement

https://mandisremotes.com/en/LG/1068089-77844-replacement-remote-control-for-LG-AKB73616006.html