Original		Replacement	
STANDBY	Power		Power
AV	AV	RDS AV INPUT	AV / Input / RDS
Mute	Mute	DIMMER MUTE	Mute / Dimmer
16:9	16:9	FORMAT PICTURE	Picture / Format
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
SUBT	Subt.	EQ SUBTITLE	Subtitle / EQ
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
7	7	AUX-HDD 7	7
8	8	USB 8	8

Original		Replacement	
9	9	BLUETOOTH 9	9
INFO	Info	ANGLE INFO	Info / Angle
BACK	Back	RETURN BACK	Back / Return
0	0	HDMI-SAT 0	0
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
VOL-	Vol -	VOL −	Vol -
VOL+	Vol +	+ VOL	Vol +
PR-	PR-	CH PAGE −	CH- / Page-
PR+	PR+	+ CH PAGE	CH+ / Page+
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat

Original	Replacement	Original	Replacement
Yellow	YouTube / REPEAT A-B: Yellow / YouTube / Repeat		
Blue	Prime Video / RANDOM: Blue / Prime Video / Random		
TXT	GOTO / TEXT: Text / Goto		
♪	TITLE / SOUND: Sound / Title		
[ ]	LIST / SMART: Smart / List		
Swap	TIMER / SLEEP: Sleep / Timer		
PIP	TOP MENU / D.MENU: D. Menu / Top		
Pos	OPT-TOOLS / SETUP: Setup / OPT /		
Size	SHIFT + SIZE / ZOOM: Shift + Zoom /		
Freeze	STEP-FREEZE / II: Pause / Step / Freeze		

Original	Replacement	Original	Replacement
Power	Power	9	9
AV	AV / Input / RDS	Info	Info / Angle
Mute	Mute / Dimmer	Back	Back / Return
16:9	Picture / Format	0	0
Zoom	Zoom / Size	Exit	Exit / Cancel / Clear
Subt.	Subtitle / EQ	Menu	Menu / Home
Audio	Audio / Lang I/II	Up	Up
1	1	Left	Left
2	2	OK	OK
3	3	Right	Right
FAV	Fav / Marker / PC	Down	Down
4	4	Vol -	Vol -
5	5	Vol +	Vol +
6	6	PR-	CH- / Page-
EPG	Guide / EPG / -/--	PR+	CH+ / Page+
7	7	Red	Red / Netflix / Search
8	8	Green	Green / APP / Repeat

Original	Replacement	Original	Replacement
Yellow	YouTube / REPEAT A-B Yellow / YouTube / Repeat		
Blue	Prime Video / RANDOM Blue / Prime Video / Random		
TXT	GOTO TEXT Text / Goto		
♪	TITLE SOUND Sound / Title		
[ ]	LIST SMART Smart / List		
Swap	TIMER SLEEP Sleep / Timer		
PIP	TOP MENU D.MENU D. Menu / Top		
Pos	OPT-TOOLS SETUP Setup / OPT /		
Size	SHIFT + SIZE ZOOM Shift + Zoom /		
Freeze	STEP-FREEZE ⏸ Pause / Step / Freeze		