Mandis shop

REMCON1483

Original	Replacement
Power	Power
Mode	Smart / List
Rotate	Green / APP / Repeat
Setup	Setup / OPT /
Up	Up
Zoom	Zoom / Size
Left	Left
Enter	OK
Play	Play / Slow
Pause	Pause / Step / Freeze
Right	Right
Timer	Sleep / Timer
Down	Down
Back	Back / Return
I<<	I<< / Preset-
[O]	Subtitle / EQ
>>I	>>I / Preset+

Original	Replacement
[ ]	Picture / Format
♫	Audio / Lang I/II
[ ]♫	TV/Radio /
Vol -	Vol -
Mute	Mute / Dimmer
Vol +	Vol +

https://mandis.es/en/Belson/106/14875-replacement-remote-control-for-Belson-REMCON1483.html