Mandis shop

REMCON1434

Original	Replacement
Power	Power
TV/FM	TV/R
Scan	VOD
Zoom	WIDE
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
+100	-/-- / EPG
Loop	P/C / FAV
Vol +	VOL +

Original	Replacement
Vol -	VOL -
CH+	CH +
CH-	CH -
Mute	MUTE
Source	SRC
+	RIGHT
-	LEFT
Function	OK
Freq Up	Fast Forward
Freq Down	Rewind
Freeze	Pause
Reset	EXIT
Seek ↑	UP
Seek ↓	DOWN

https://mandis.com/Best-Buy/1033-229-replacement-remote-control-for-Best-Buy-REMCON1434.htm