Mandis shop

Samsung DJ96-00114G

Original		Replacement		Original	Replacement
Power	Power		Power		
Recharging	Recharging	Aspect / Eco	Eco / Aspect		
Auto	Auto	Auto	Auto		
Spot	Spot	Source	Source		
Max	Max	Mode	Mode		
	Up		Up		
	Right		Right		
	Left		Left		
Start/Stop	Start/Stop	Enter	Enter		
Manual	Manual	Video / Comp	Comp / Video		
Edge	Edge	Page▲ / Vol	Vol + / Page +		
Clock	Clock	Menu	Menu		
Timer/Daily	Timer/Daily	Timer / Freeze	Freeze / Timer		
	No Name Left	Play	+ / Play		
	No Name Right	Focus / Volt	Volt / Focus		

https://mandisremotes.com/en/Samsung/1059728-79362-replacement-remote-control-for-Samsung-DJ96-00114G.html