Mandis shop

TT-SK15

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Mute | MUTE | Mute |
| BT | BT | 1 | 1 |
| | Audio / Aux | 2 | 2 |
| COAX | COAX | 3 | 3 |
| OPT | OPT | SETTINGS OPT | Options |
| OPT | OPT | 4 | 4 |
| + | + | | Up |
| + | + | + VOL | Vol + |
| - | - | | Down |
| - | - | VOL - | Vol - |
| | >>I | | >>I |
| | >>I | | >> |
| | >>I | | Right |
| | I<< | | I<< |
| | I<< | | << |
| | I<< | | Left |

| Original | | Replacement | |
|---|---|---|---|
| | Play/Pause | PLAY MODE | Play |
| | Play/Pause | | Pause |
| | Play/Pause | OK | Ok |

https://mandisremotes.com/en/TaoTronics/1061975-92317-replacement-remote-control-for-TaoTronics-TT-SK15.html