Original	Replacement
Power	Power
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Input	AV
Recall	Back
PP	Smart
Menu	Menu
Exit	Exit

Original	Replacement
Up / P+	Up
Up / P+	Ch +
Left	Left
OK	Ok
Right	Right
Down / P-	Down
Down / P-	Ch -
V+	Vol +
V-	Vol -
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Aspect	Format
Audio I-II	Dual
Text	Text
Text Reveal	Play

Original	Replacement	Original	Replacement
Text Hold	Stop		
Text Size	Rec		
Text Timer / Text Cancel	Pause		
Sound	SHIFT + DUAL: Shift + Dual		
Sound):	>>		
Text Index / Call	I <<		
Text Index / Call	Info		