Mandis shop

Pioneer RC-957R

Original	Sustituto	Original	Sustituto
Power	Power	Down	Down
Stereo	Dual	Left	Left
<	Ch -	Home	Smart
>	Ch +	Right	Right
BD / DVD	1	Back	Back
CBL / SAT	2	Vol +	Vol +
Game	3	Home	Menu
NET	4	Vol -	Vol -
Bluetooth	5	Mute	Mute
USB	6	Auto / Direct	List
Tuner	7	SURR	Subt
TV	8	I <<	I <<
CD	9	Play / Pause	Play
AV Adjust	AV	Play / Pause	Pause
i / Status	Info	>>I	>>I
Up	Up	Repeat / Shuffle Clear	Exit
Enter	Ok	+ FAV	Pre Ch

Original	Sustituto	Original	Sustituto
MODE Mode	APP MEDIA Medi a		