Mandis shop

Sony 200064

Original		Sustituto	
	POWER		Power
	INPUT		AV
	PIC. MODE -		4
	PIC. MOD. - STANDARD		5
	PIC. MODE -		6
	USER 1		1
	USER 2		2
	USER 3		3
	LENS		Info
	RESET		Exit
	MENU		Menu
	UP		Up
	LEFT		Left
	ENTER		Ok
	RIGHT		Right
	DOWN		Down
	GAMMA CORRECTION		7

Original		Sustituto	
	Black Level		Back
	ADVANCED IRIS		8
	COLOR SPACE		9
	COLOR TEMP		0
	WIDE MODE		Red
	RCP		Green
	ADJ. PIC.		Yellow
	SHARPNESS+		Smart
	SHARPNESS-		Media
	BRIGHT. +		Vol +
	BRIGHT. -		Vol -
	CONTRAST+		Ch +
	CONTRAST-		Ch -

CORRECTION

https://mandis.es/es/Sony-10331-928-mando-sustituto-para-Sony-RM-PJVW70-187072.html