Mandis shop

RC-393

Original		Sustituto		Original	Sustituto
COUNTER CLEAR	Counter Clear	CLEAR EXIT	Exit		
DISPLAY	Display	DISPLAY INFO	Info		
AUTO MONITOR	Auto Monitor	HOME SMART	Smart		
REC MUTE	Rec Mute	MUTE	Mute		
RECORD	Record	REC MODE	Rec		
PAUSE	Pause		Pause		
<<	<<	<<	<<		
>>	>>	>>	>>		
STOP	Stop		Stop		
PLAY	Play	PLAY MODE	Play		

https://mandisremotes.com/es/Teac/1063866-93176-mando-de-sustitucion-para-Teac-RC-393.html