Mandis shop

Panasonic N2QAYB001050

Original		Sustituto	
	Power		Power
DIMMER	Dimmer	HOME SMART	Smart
CD	Open/Close CD	ZOOM	Eject
	Bluetooth	APP MEDIA	Media
CD/ USB	CD/ USB	TIMER AV	AV
RADIO/ EXT-IN	Radio/ EXT-In	SEARCH TV/R	TV/R
	<<		<<
	Pause		Pause
	>>I		>>I
	Stop		Stop
	I <<		I <<
VOL+	Vol +	+ VOL	Vol +
	>>		>>
VOL–	Vol -	VOL –	Vol -
	Play	PLAY MODE	Play
MUTE	Mute	MUTE	Mute
SETUP	Setup	SETTINGS OPT	Options

Original		Sustituto	
DISPLAY	Display	DISPLAY INFO	Info
SOUND	Sound	SOUND DUAL	Dual
PLAY MENU	Play Menu	TOP MENU MENU	Menu
	Album Up		Up
OK	OK	OK	Ok
	Album Down		Down