Mandis shop

Panasonic VEQ1195

Original	Sustituto	Original	Sustituto
Operation	Power		
Audio Out	Mute / Dimmer		
Rec	Rec / Rec Mode		
Pause / Still	Pause / Step / Freeze		
Still ADV	Right		
Stop	Stop / Hold		
Rew	<< / Tune-		
FF	>> / Tune+		
Play	Play / Slow		
Slow	OK		
Slow	SHIFT + SLOW		
Slow-	Down		
Slow+	Up		

https://mandis.es/es/Panasonic/1033-952-mando-sustituto-para-Panasonic-VEQ1195.htm