Mandis shop

LG COV31069401

Original	Sustituto	Original	Sustituto
Power	Power	Stop	Stop / Hold
EQ	Subtitle / EQ	Stop	OK
*	Audio / Lang I/II	>> / >>I /	>> / Tune+
Open/Close	Eject / Surround	>> / >>I /	>>I / Preset+
Preset/Folder+	CH+ / Page+	>> / >>I /	Right
Function	Smart / List	Program/Memo	TV/Radio /
Volume+	Vol+	Play/Pause	Play / Slow
Preset/Folder-	CH- / Page-	Play/Pause	Pause / Step / Freeze
Mute	Mute / Dimmer	Play/Pause	Down
Volume-	Vol-	Rec	Rec / Rec Mode
Sleep	Sleep / Timer		
Repeat	Green / APP / Repeat		
Repeat	Up		
Info	Info / Angle		
<< / I<< / Tun-	<< / Tune-		
<< / I<< / Tun-	I<< / Preset-		
<< / I<< / Tun-	Left		

https://mandis.es/es/LG-COV31069401.htm