Mandis shop

POLK AUDIO 981307102280K

Original		Sustituto	
	Power		Power
1	HDMI 1	1	1
2	HDMI 2	2	2
3	HDMI 3	3	3
TV	TV	PROGRAM TV/RADIO	TV/Radio /
	Bluetooth	9	9
BASS	Bass+		Up
VOL	Vol +	VOL	Vol +
VOICE	Voice+	CH PAGE	CH+ / Page+
BASS	Bass-		Down
VOL	Vol -	VOL	Vol -
VOICE	Voice-	CH PAGE	CH- / Page-
	Mute	DIMMER MUTE	Mute / Dimmer
MOVIE	Movie	EQ SUBTITLE	Subtitle / EQ
MUSIC	Music	LANG I/II AUDIO	Audio / Lang I/II
NIGHT	Night	CLEAR EXIT CANCEL	Exit / Cancel / Clear
3D	3D	FORMAT PICTURE	Picture / Format

Original		Sustituto	
SPORT	Sport	RETURN BACK	Back / Return
VOLUME SURROUND	Volume Surround-	SHIFT + VOL	Shift + Vol -
VOLUME SURROUND	Volume	SHIFT + VOL	Shift + Vol +
BALANCE L	Balance L		Left
BALANCE R	Balance R		Right

https://mandis.es/es/POLK-AUDIO-981307102280K-mando-sustitucion-para-POLK-AUDIO-981307102280K.htm