Mandis shop

LG AKB74815376

Original		Sustituto	
	Power		Power
F	F	TOP MENU MENU	Menu
VOL +	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL -	Vol -
	Mute	MUTE	Mute
ASC (III)	ASC (III)	SETTINGS OPT	Options
STANDARD	Standard	SOUND DUAL	Dual
CINEMA	Cinema	AD SUBT	Subt
>>I	>>I	>>I	>>I
I<<	I<<	I<<	I<<
	Play	PLAY MODE ▶	Play
	Pause	II	Pause
NIGHT ON	Night On	▲	Up
NIGHT OFF	Night Off	▼	Down
WOOFER LEVEL +	Woofer Level +	+ CH	Ch +
WOOFER LEVEL -	Woofer Level -	CH -	Ch -
AUTO POWER ON	Auto Power On	HOME SMART	Smart

Original		Sustituto	
AUTO POWER OFF	Auto Power Off	APP MEDIA	Media

https://mandis.es/es/LG-AKB74815376-mando-sustitucion-para-LG-AKB74815376.htm