Original	Sustituto	Original	Sustituto
On/Off	Power	Exit	Exit
Audio Out	Mute	Menu Down	Down
Slow Down	Shift + Pause	Tracking+	Ch +
F. Adv	List	Audio	Dual
Auto/Track	Smart	Tracking-	Ch -
Stop	Stop	1	1
Pause	Pause	Next	>>I
Slow/Dpss-	Vol -	2	2
Mon/TV	TV/R	Otr/A.Otr	Blue
Video/Go-To	D. Menu	3	3
Sp/Lp/Speed	Text	X2 Rew/Play	Subt
VCR/TV	AV	P. Back/R. +Play	Back
Menu	Menu	4	4
Menu Up	Up	Vps/Pdc	Ok
Slow/Dpss+	Vol +	Prev.	I <<
Display	Info	5	5
T. Set/Clock	Yellow	Store	Media

Original	Sustituto
6	6
7	7
8	8
9	9
-/--	Guide
Rec. On/Off	Options
0	0
Clear 00:00	Shift + Exit
Rec/Mode	Shift + Rec
Progr/C/CH	Pre Ch
Skip/Search	Format
F. Forward	>>
Play	Play
Counter Reset	Green
Eject/Reverse	Eject
Search Index	Shift + TV/R
Timer/Record	Shift + AV

Original	Sustituto
Rewind	<<
Timer/Sleep	Sleep
Record	Rec
Counter Clock	Red