Mandis shop

Pioneer CU-A002

Original	Sustituto
Tape Sel	Media
<< Tape Deck I	<<
<< Tape Deck	Shift + <<
>> Tape Deck	Shift + >>
>> Tape Deck I	>>
< Tape Deck II	Shift + Left
< Tape Deck I	Left
Stop Tape Deck I	Shift + Ok
Stop Tape Deck I	Ok
> Tape Deck I	Right
> Tape Deck II	Shift + Right
Disc Sel	Smart
I<< CD	I<<
>>I CD	>>I
CD Power	1
Stop CD	Stop
Play CD	Play

Original	Sustituto
Tuner Power	2
- Station Tune	Ch -
Station + Tuner	Ch +
AMP Power	Power
Tape 1	Red
Tape 2	Green
Function	Menu
Volume-	Vol -
Volume+	Vol +