Mandis shop

Sharp RRMCG0028SJSA

Original	Sustituto	Original	Sustituto
On/Standby	Power	Sleep	Sleep
CD	Red	Clock	Smart
Video/AUX	Green	Clear	Exit
Tuner	Yellow	Timer	AV
Band	Blue	Random/Repeat	Text
Play	Play	Memory	Menu
Pause	Pause	Dimmer	Media
Stop	Stop	Surround	Dual
>>I	>>I	Bass Up	Ch +
I <<	I <<	Bass Down	Ch -
Vol +	Vol +	Treble Down	Left
Vol -	Vol -	Treble Up	Right
Preset Up	Up	Display	Info
Preset Down	Down	EON	Subt
>>/Tuner Up	>>	PTY-TI	TV/R
<<</Tuner Down	<<	ASPM	3D
Open/Close	Eject		

https://mandisshop.es/Sharp/1635-246-mando-sustituto-para-Sharp-RRMCG0028SJSA.htm